

# User manual

# LAK901





## **Table of contents**

Warning and safety instructions:	3
Product description	5
Commissioning	6
The LED	6
Home screen	8
Alarm call	9
Battery alarm	9
Main menu	10
Main menu - Hibernate (sleep)	11
Main menu - Settings	12
Main menu - Settings - Sensitivity	13
Main menu - Settings - Time management	17
Main menu - Settings - Advanced	20
Main menu - Settings - Set the clock	25
Main menu - Settings - Wireless	26
Main menu - Settings - Turn off	28
Maintenance	29
Cleaning	30
Check the coverage area	30
Spare parts and accessories	30
Technical data	31
Explanation of symbols and approvals	32

## **Warning and safety instructions:**



- The battery in this product complies with the relevant IEC safety standards for batteries.
- Please read the safety instructions on the power supply before use.
- The power supply unit must meet the relevant IEC safety standards.
- When replacing the power supply unit, original or/and approved units must be used.
- The battery must not be replaced, and the product must be sent for repair.
- Please read the intended use before putting it into service.
- The product is not water-resistant unless noted in product specification.

## **Contraindications**

In general, the product cannot be used if:

- The disabled client/patient is mentally ill.
- The disabled client/patient is critically ill.
- The client/patient is unable to use the transmitters.

## **Lifetime after mounting of the device**

The battery, if applies, must be replaced when the battery replacement information appears on the display and according to the user manual.

Lifetime is evaluated in relation to the pressure button. This is made according to the supplier's specification.

## **Lifetime battery (products using battery, only)**

KNOP calculates the life of the batteries. See specification in the user manual.

## **Intended use**

In general, the different variants of the medical device (transmitters/receiver system from KNOP Elektronik) are made as assistive aid for impaired/disabled patients to be able to call for assistance.

The various variants of the medical equipment consist of a combination of products (transmitter and receiver) designed to call for help to impaired/disabled patients; The transmitter-receiver system can be activated in different ways:

- For example, patients who actively do this and are aware that they are calling for help, such as e.g., people with walking difficulties who need help going to the toilet.
- Or disabled patients who are not aware that they are inadvertently putting pressure on the sendere.g. during a seizure.

**© KNOP Elektronik A/S**

Fabriksvej 20 ● DK-7600 Struer ● knop@knop.dk ● knop.dk ● +45 97840444



- Or patients with intellectual and cognitive deficits who are not aware that a receiver is receiving a signal from their transmitter when they leave a house or room.

The system is not designed for critically or mentally ill persons.

## **General product description**

The products manufactured by KNOP elektronik consist of several variants of transmitters and receivers that can be combined with each other. In addition, these products are used in combination with positioning and repeater systems.

These products are medical devices intended to call for assistance and are used for disabled/mobile people, such as those with walking difficulties who need help going to the toilet. The transmitters are activated, for example, by a sound or by pressure (e.g. by pressure with a finger or a breath through the mouth). The recipient is supervised by health care personnel or lay people in private homes.

The system is not designed for critically or mentally ill people.

Part of product	Function in the product system
Transmitter	The transmitter can send the signal obtained from the patient to the receiver monitored by the healthcare personnel or lay person. The transmitter products can be activated by button, sound, blow or movements.
Receiver	The transmitters can be coded into all the receivers and to several receivers at the same time. Some receivers also have a summon button for calling assistance from their coworkers.
Repeatersystem	If it is needed to cover a more comprehensive and larger area a repeater system is used. The repeater system also gives an increased functionality as e.g. that an alarm automatically is received at first at the healthcare person closest to the client.
Positionsystem	If a sender is equipped with a position receiver it can be used in connection with a Position system. Not all product variants include position receivers. Typically, it is seen in connection with nursing homes and security for patients with dementia. The receivers can be portable or stationary.



## ***Product description***

LAK901 is designed to work with KNOP 90X series wireless devices.

The transmission takes place when LAK901 detects a sound at a certain level. Pay attention to the range as described in the section "Checking the coverage area".

LAK901 is designed to assist clients in situations where the client cannot activate a normal paging system but can make an audio callout.

LAK901 is equipped with a position reader, so the current position of the product can be used in KNOP's positioning system.

With LAK901 it is possible to make an emergency call to another colleague with a single press of the KNOP logo.

Operation is menu-driven in a graphical display and controlled via the keyboard.

LAK901 has a rechargeable battery and can be charged with a micro-USB cable.

It is possible to connect an external microphone and an external monitor with speakers. Both are available as accessories.

## Commissioning

It is recommended that LAK901 be charged to 100% or permanently connected to a power supply before use.

LAK901 is connected to the charger. When you connect the charger, the product will turn on automatically if it is switched off, otherwise, press **Ent** and the product will turn on.

When the product is switched on for the first time, the desired language must be selected.



Press **Up** **Down** to change the setting.

**ENTER** Press **Ent** to accept the new language.

**OFF** Press **Esc** to turn off the product.

## The LED


The LED indicates:

- Green: Send telegram.
- Flashing green: Telegram received.
- Flashing red: Telegram not answered.
- Short red flashing: Low battery, charge the battery.
- Short green flashing: The product is in sleep mode (but not if the light function is switched off).

## Connections

There are four contacts in the product.

1. External relay output and external power supply
2. Connection to LAK901M, external audio monitor.
3. External KNOP microphone.
4. Charging connector, MicroUSB.



External output/power supply. Plug for LAK901M External microphone. MicroUSB charger.


1. Minus
- 2.
3. 8-15V @100mA
- 4.
- 5.
- 6.
7. Relay (NO)
8. Relay (COM)



## Home screen

When the device is switched on for the first time after it has been unpacked, the charger must be connected.

The screen will automatically turn off after about 15 seconds after the last operation.  
Pressing any key turns the display on and shows the clock, date, and status.  
The user's name is shown at the top if coded.



### Home screen options:



For example, the name of a product or a location can be changed to the desired name.



The current time and date are displayed in white text.



The clock must be set.



Microphone status and activation.



The microphone is activated, and the time recording has started.



Timekeeping has started and an alarm has been sent.



Locking activated, microphone alarm not possible.



The charger is connected.  
The battery is charged.  
Charging is recommended.  
The battery is next used and needs charging soon.  
Unknown battery status, please wait.



The internal microphone is on.  
The internal microphone is off.  
The external microphone is on.  
The external microphone is off.



The timer is activated and is **within** the active period.  
The timer is activated and is **outside** the active period.  
The timer is deactivated.



## Alarm call

It is possible to make either an emergency call or an alarm call from the product to e.g. staff to indicate "I need help" with a client or as an assault alarm.

The call must be acknowledged by a receiver, after which "OK" is displayed. If this does not happen, "FAILED" is displayed. If the call fails, the call is automatically repeated twice.

See "Main Menu - Settings - Wireless" to set up the call.

The call is activated by pressing the logo button.

### Panic call



Call sent.



Call failed.




Call received.


### Alarm call



Call sent.



Please wait



Call failed.



Call received.

## Battery alarm



The battery is charged.




Charging is recommended. The battery is running low and needs charging.





If the symbol changes to red, connect the charger immediately.

At the same time, a pair of short beeps sounds about every five minutes, indicating low battery, while the screen below appears:










## Main menu


By pressing and  holding  for 1 second, either when the screen is off or on the home screen, the main menu is displayed. However, the product must be switched on.

### General information about the menu



In this example,  is the  function of the button (accept) and  is the  function of the button (cancel/exit menu) are



The green arrow shows which menu item can be selected by pressing .

Press   to move the green arrow up/down or right/left in the menu.

**NOTE:** After about 30 seconds of inactivity, the menu will automatically exit.



## Main menu - Hibernate (sleep)



- ENTER** Select the **Hibernate (Sleep)** menu item and press **Ent**.
- EXIT** Press **Esc** to exit the menu.



- YES** Press **Ent** to accept.
- EXIT** Press **Esc** to exit the menu.

The product is switched on again by pressing **Ent**.

If you want to turn the receiver off completely, you can do so in the menu item "Settings ➔ Turn off".

Sleep mode can be used if you do not want to receive calls from the product for a certain period. Sleep mode consumes more power than "off-mode".




## Main menu - Settings



- ENTER** Select **Settings** and press **Ent**.
- EXIT** Press **Esc** to exit the menu.

If a password has been programmed, it must now be entered.




- Press **↑** **↓** to change the value (0 to 9).
- ENTER** Press **Ent** to select a number.
- BACK** Press **Esc** to delete the last digit or return to the main menu.

*With the wrong code:*

- CANCEL** Press **Ent** to try again.
- EXIT** Press **Esc** to exit the menu.

The settings menu now appears:



The software version and product ID are displayed on the first two lines and cannot be changed.

**S/W: 10.0** Software version.  
**ID: 12345** Product ID and serial number.

- ENTER** Select a menu item and press **Ent**.
- EXIT** Press **Esc** to exit the menu.



## Main menu - Settings - Sensitivity

Set the microphone sensitivity and activation time.




**ENTER** Select **Sensitivity** and press **Ent**

**EXIT** Press **Esc** to exit the menu.



The sensitivity can be set between 0 and 100 % and the activation time between 0 and 5.0 seconds.




The microphone **can't** hear anything.  
The microphone hears something.

Press **Up** **Down** to change the sensitivity of the microphone.

**NEXT** Press **Ent** to change the activation time.

**EXIT** Press **Esc** to leave the menu unchanged.





The activation time can be set between 0 and 5.0 seconds.

Press **Up** **Down** to change the sensitivity of the microphone.


**NEXT** Press **Ent** to test the settings.

**BACK** Press **Esc** to go back to the sensitivity adjustment.



Activate the microphone with the desired sound. The microphone icon is red  when something is heard. As soon as something is heard, the activation time starts, something must be heard all the time during the set time, otherwise, the time starts again. If something is heard during the whole period, the hourglass turns red  corresponding to an activated alarm.

**SAVE** Press  to save the settings.

**BACK** Press  to go back to the activation time adjustment.

### Microphone frequency filter

Frequency filters are used to attenuate unwanted sounds or noise. Depending on the sound the client wants, the filters can be adjusted to optimize this. For example, it is only possible to say sounds like O and B. If these sounds are in the 500 Hz range, it is a good idea to set the filters at 250 Hz (bass filter) and 1000 Hz (treble filter) so that these particular sounds dominate. On the other hand, whispering sounds such as S and T, 2000 Hz (bass filter), and 6000 Hz (treble filter) are better.

By default, the files are set to 250 Hz (bass filter) and 4000 Hz (treble filter), which covers the normal speech range.


#### Example:

- Whistles or flutes are usually loud i.e., in the treble, and the filters can be set to 2000 Hz in the bass filter and 6000 Hz in the treble filter.
- If the client mainly have buzzing sounds, they are usually in the bass range and the filters can be set to 250 Hz in the bass filter and 1000 Hz in the treble filter.
- If the client can use the speech range for both men and women, the default setting is 250 Hz in the bass filter and 4000 Hz in the treble filter.



**ENTER** Select the **Advanced** menu item and press .

**EXIT** Press  to exit the menu.



- ENTER** Select the **Bass filter** or **Treble filter** menu item and press **Ent**
- EXIT** Press **Esc** to exit the menu.



- ENTER** Select the desired frequency and press **Ent**.
- EXIT** Press **Esc** to leave the menu unchanged.

## Blocking time

After the microphone has been activated and an alarm has been sent, a blocking time can be selected. During the lock time, the product cannot send an audible alarm until the time has expired. It is possible to turn off the lock time.

The function reduces the number of repeated alarms in the same activation. By default, the product is set to 90 seconds.




- ENTER** Select the **Blocking time** menu item and press **Ent**.
- EXIT** Press **Esc** to exit the menu.



- ENTER** Select the desired time and press **Ent**.
- EXIT** Press **Esc** to leave the menu unchanged.

## Reset microphone settings



- ENTER** Select the menu item **Reset** and press **Ent**.
- EXIT** Press **Esc** to exit the menu.



- YES** Press **Ent** to reset the microphone settings to factory defaults.
- EXIT** Press **Esc** to leave the menu unchanged.









## Main menu - Settings - Time management

The product has four timers that can turn the microphone on and off throughout the day and week.  
**IMPORTANT:** If the clock is not set, the timer automatically turns off and the microphone is therefore always active.



- ENTER** Select the **Time management** menu item and press **Ent**  
**EXIT** Press **Esc** to exit the menu.



-  The timer is programmed but is not within the programmed time.  
 The timer is programmed and is within the programmed time.  
 The timer have not programmed.

- ENTER** Select the desired timer and press **Ent**.  
**EXIT** Press **Esc** to exit the menu.



- Activated: Yes** The timer is on.  
**Activated: No** The timer is NOT on.

- Start: 8:00** Start time  
**Stop: 16:00** Stop time

- MTWTFSS** The timer is on during these days of the week. The green marking is on during the day.

- Save?** Save the timer setting.

© **KNOP Elektronik A/S**



### Activation



- FLIP** Press to switch between yes and no.
- EXIT** Press to leave the menu unchanged.

### Start/stop time



- Press to change hours/minutes.
- NEXT** Press switch to the next setting.
- BACK** Press to go back to the menu.



- Press to change the day.
- FLIP** Press to switch between deselecting (red) and selecting (green).
- BACK** Press to go back to the menu.




Save!

```
Timer 1
Activated: Yes
Start: 8:00
Stop: 16:00
MTWTFSS
→ Save?
SAVE EXIT
```

**SAVE** Press **Ent** to save the settings.  
**EXIT** Press **Esc** to leave the menu unchanged.




## Main menu - Settings - Advanced



**ENTER** Select the **Advanced** menu item and press **Ent**.

**EXIT** Press **Esc** to leave the menu.

### Light & Sound



**ENTER** Select the desired menu and press **Ent**.

**EXIT** Press **Esc** to leave the menu.

#### Backlight:

The brightness of the screen.

#### Light function:

Off, the display turns on when in use.

Activity, the display is on for sounds and alarms (dimmed).

Auto/Down, the display is normally off in battery mode, otherwise, it is dimmed.

#### Important sounds:

The volume of a keystroke.



**SAVE** Press **Ent** to save the settings.

**EXIT** Press **Esc** to leave the menu unchanged.



## Language

Main menu	Settings	Advanced
Hibernate → Settings	↑ Microphone Timer setup → Advanced Clock adjust ↓ Wireless	Light & Sound → Language Daylight-saving Product name Password
ENTER EXIT	ENTER EXIT	ENTER EXIT

**ENTER** Select the **Language** menu item and press **Ent**.

**EXIT** Press **Esc** to exit the menu.

Language	Language
↑ Svenska Norsk Suomi → English Deutsch	↑ Norsk Suomi → English Deutsch Español
OK EXIT	OK EXIT

Set the desired language in the product.

Press **↑** **↓** to change the setting.

**ENTER** Press **Ent** to accept the new language.

**EXIT** Press **Esc** to exit the menu.

## Daylight-saving

It is possible to turn on or off the automatic summer/wintertime. Normally it is set to automatic.


Main menu	Settings	Advanced
Hibernate → Settings	↑ Microphone Timer setup → Advanced Clock adjust ↓ Wireless	Light & Sound Language → Daylight-saving Product name Password
ENTER EXIT	ENTER EXIT	ENTER EXIT



**ENTER** Select the **Daylightsaving** menu item and press **Ent**.

**EXIT** Press **Esc** to exit the menu.

**Manually:** Unchanged.

**Automatically:** Automatically changed twice a year.






- ENTER** Press  to save the settings.
- EXIT** Press  to leave the menu unchanged.









### Product name

The name of this LAK901 can be changed to a more meaningful name e.g., "Peterson", which in this example is the client of this product. This is an optional feature that can be used. By default, LAK901 is displayed.




- ENTER** Select the menu item **Product name** and press .
- EXIT** Press  to leave the menu.



- Press   to change the letter.
- ENTER** Press  to select a letter.
- BACK** Press  to delete the last letter.
- ENTER** Press  for about 1 second to switch between lowercase and uppercase letters.
- ENTER** Press  for about 3 seconds to jump to the save icon.
- BACK** Press  for about 3 seconds to exit the menu.
- Press  to switch between regular and special letters.



- ENTER** To save the name, select the symbol  and press **Ent**.
- EXIT** Press **Esc** för att lämna menyn oförändrad.

## Password

To avoid accidental changes to the settings, the menu can be protected with a password. The password is a four-digit code.

The code "0000" means that there is no code!



Once a password has been created, you must enter it before you can access the settings menu.


**If you want to delete a password, enter "0000"!**



- ENTER** Select the **Password** menu item and press **Ent**.
- EXIT** Press **Esc** to exit the menu.



- Press   to change the value (0 to 9).
- ENTER** Press **Ent** to select a number.
- BACK** Press **Esc** to delete the last digit.
- BACK** Press **Esc** and press and hold for 2 seconds to exit the menu.



**SAVE** Press **Ent** to save the code.

**EXIT** Press **Esc** to leave the menu unchanged.


**NOTE:** Saving can only be done when all four digits are selected.






## Main menu - Settings - Set the clock

It is important that the time and date are set correctly for the time controls to work properly. If the clock is not set, it is not possible to activate the time control.



- ENTER** Select the **Set clock** menu item and press **Ent**.  
**EXIT** Press **Esc** to leave the menu.

### Set clock



Press to change the setting.

- NEXT** Press **Ent** to go to the next one.  
**BACK** Press **Esc** to go back or exit the menu.

### Save new clock




- SAVE** Press **Ent** to save the settings.  
**BACK** Press **Esc** to leave the menu unchanged.

**NOTE:** If a KNOP system (MR902/RP902/USB901) is used, the clock is updated automatically. Alternatively, the product tries to keep the clock updated with other products that have a more recent setting.



## Main menu - Settings - Wireless



**ENTER** Select the **Wireless** menu item and press **Ent**.

**EXIT** Press **Esc** to exit the menu.

### KNOP logo



**ENTER** Select the **KNOP logo** menu item and press **Ent**.

**EXIT** Press **Esc** to exit the menu.

The KNOP logo on the product can be used to call others if this is programmed into their receiver. The button can either send a normal alarm call, an emergency call or be cancelled.

**Deactivated:** KNOP button does not send anything.

**Panic alarm:** KNOP button an emergency call to all recipients who can receive the call.

**Normal alarm:** KNOP button sends a call to the receiver where this are encoded.



**ENTER** Press **Ent** to save the settings.

**EXIT** Press **Esc** to leave the menu unchanged.



## Radio

It is possible to turn the wireless transmitter on or off in the product. It is advisable to switch off the transmitter only if the relay output of the product is used so that the product does not transmit signals unnecessarily and the battery life is extended.




**ENTER** Select the **Radio** menu item and press **Ent**.

**EXIT** Press **Esc** to exit the menu.

No audible alarms are sent when it is disconnected.

Connected sends audible alarms.

If the KNOP logo is set to send an alarm, it works in both cases.



**ENTER** Press **Ent** to save the settings.

**EXIT** Press **Esc** to leave the menu unchanged.



## Main menu - Settings - Turn off

Turns the product off completely and can only be turned back on by pressing **Ent**.



**ENTER** Select the **Language** menu item and press **Ent**.

**EXIT** Press **Esc** to exit the menu.



**YES** Press **Ent** to accept.

**EXIT** Press **Esc** to exit the menu.

If you simply want to put the product to sleep, you can do so in the "Settings ➔ Hibernate" menu.

**Note:** The clock and date are reset.

## Maintenance

### Update of LAK901

It is possible to update the software of LAK901, as well as to download and transfer settings with KNOPtool. For further information at our homepage [www.knop.dk](http://www.knop.dk)

### Resetting the product

Switch off the product completely and remember to remove the adapter or external power supply before doing so.

Immediately afterward, press and hold **Ent** **Esc** for about 1 second, release **Ent**, and continue pressing **Esc** while the LED flashes red.

Press and hold the button until the LED turns green.

Then release the **Esc** button.

The product can then be switched on again by pressing **Ent**.

### Restart the product


Hold **Esc** for about 30 seconds until the product restarts. Then release the **Esc** button.

The product can then be switched on again by pressing **Ent**.

### Battery failure and replacement

The product displays "BATTERY ERROR" when the battery needs to be replaced.

The battery may only be replaced with an original KNOP Elektronik battery.  
See the instructions supplied with the new battery.





## ***Cleaning***

The product can be cleaned with a moist cloth or a wet wipe.

## ***Check the coverage area***

One person activates the product at short intervals, while another person systematically walks around the area and marks on a sketch the building and the area where there is coverage. The map is placed in the office so that anyone who needs to use the system can see where there is coverage. Outside the coverage area, alarms cannot be received.

The coverage area can be extended using the KNOP repeater system.  
Contact your retailer for more information.

## ***Spare parts and accessories***

Spare parts and accessories can be ordered from Knop Elektronik A/S at [www.knop.dk](http://www.knop.dk).



## Technical data

<b>Frequency HF:</b>	869.2125 MHz
<b>Range:</b>	Up to 1500 m between LAK901 and RX901B <sup>(1)</sup>
<b>Battery:</b>	Lithium battery, LP853048 3.7V 1200mA
<b>Battery time:</b>	Approximately 14 days with 10 alarm calls per day depending on settings.
<b>Charge:</b>	230VAC adapter USB 5VDC/1,0A
<b>Charging time:</b>	90 minutes.
<b>Display:</b>	Graphic LCD
<b>Menu languages:</b>	Danish, Norwegian, Swedish, Finnish, German, English, and Spanish.
<b>Surrounding environment:</b>	Indoor use. ≤ 90% non-condensing
<b>Ambient temperature:</b>	0 °C to +40 °C
<b>Cabinet type:</b>	Colour: RAL9001 ABS
<b>Cabinet dimensions:</b>	W: 65mm, H: 120mm, D: 20mm.
<b>Density:</b>	IP20
<b>Weight:</b>	100g















The right to make changes is reserved.

All rights reserved.

© **KNOP** Elektronik A/S

<sup>(1)</sup> Measured outdoors with a free view between transmitter and receiver. In buildings, the range is reduced.

## Explanation of symbols and approvals

	<b>This product complies with:</b> Directive 2017/745/EU      MDR Directive 1907/2006/EU      REACH Directive 2011/65/EU      RoHS Directive 2012/19/EU      WEEE ISO 14971:2019      Risk Management for Medical devices EN 301 498-1 V2.2.3      Electro Magnetic Compatibility EN 301 489-3 V3.1.1      Electro Magnetic Compatibility EN 50130-4:2011 + 2014      Immunity alarm systems EN 300 220-1 V3.1.1      Short Range Devices EN 300 220-2 V3.1.1      Short Range Devices EN 300 220-3 V2.1.1      Short Range Devices EN 60601-1-2:2014 + 2015      Electromagnetic compatibility (Medical) EN 62368-1:2020      Electrical safety EN 50581:2012      Hazardous substances
	The product must not be used if the packaging is damaged.
	<b>Medical Device</b> Class 1, rule 1
	<b>Manufacturer</b> KNOP Elektronik A/S, Fabriksvej 20, DK-7600 Struer, Denmark
	Read the manual(s) before installation and commissioning at <a href="http://www.knop.dk">www.knop.dk</a> .
	Interference may occur in an environment with equipment marked with this symbol.
	Must be protected against liquids.
	0 °C to +40 °C, temperature limit for transport/storage and use.
	The product must not be disposed of with normal household waste.
	<b>Single Registration Number</b> DK-MF-000025631
	<b>Unique Device Identifier</b> LAK901:      05744002850465 MI901:      05744002853466
	<b>Product reference</b> LAK901:      Sound alarm MI901:      External microphone
	<b>Serial number</b> Placed on the product
	<b>Ingress Protection Code</b> IP20